

# CLEANING AND CARE

**Note:** These conditions are considered to be normal maintenance and are therefore not covered by our limited lifetime transferable warranty.



Condition	<b>CorrectDeck®</b> Recommended CorrectDeck Solution	<b>CorrectDeck®CX</b> Recommended CorrectDeck CX Solution
General Cleaning	Dry sweep (weekly), pressure wash up to 1200 PSI <i>(with fan tip)</i>	Dry sweep (weekly), wash with warm, soapy water & sponge, pressure wash up to 1200 PSI <i>(with fan tip)</i>
Mold & Mildew Inhibitor	Deck Defender <i>(available at your local dealer or correctdeck.com)</i>	Not required
Mold & Mildew Removal	Armor All® EZ Deck Wash <i>(Armor All® Products can be found at most Wal-Mart stores nationwide. Check with your local hardware store or home improvement supply.)</i>	Warm, soapy water & sponge <i>(laundry detergent without bleach is best)</i>
Grease Stains <i>(food, suntan oil, etc.)</i>	Stand Off® Oil and Grease Stain Remover, Shout® Stain Remover, OxiClean®	Warm, soapy water & sponge <i>(laundry detergent without bleach is best)</i> , baby wipes for spot cleaning
Rust Stains	OxiClean®	Warm, soapy water & sponge <i>(laundry detergent without bleach is best)</i>
Construction Marks	Rubbing alcohol	Rubbing alcohol
Minor Scratches	Scratches will weather to deck color	CorrectDeck CX touch-up pens or paint stripper gun <i>(heat gun)</i>
Deep Gouges or Cuts	Deep gouges or cuts will weather to deck color or board may need to be replaced	Epoxy putty & touch-up pens available in the CorrectDeck CX Deck Care Kit
Minor Scuff Marks	Minor scuff marks will weather to deck color	Minor scuff marks will weather to deck color, or paint stripper gun <i>(heat gun)</i>
Weathering	Standard CorrectDeck will weather to a lighter shade during the first 12 weeks of exposure. Although not needed for protection, a high solids deck finish may be used to rejuvenate the color of the deck.	CorrectDeck CX semi-gloss surface will weather to a natural matte finish over time. Dry sweep and wash with warm, soapy water to remove dirt and grime.
Bird Droppings	Wash with warm, soapy water & sponge, pressure wash up to 1200 PSI <i>(with fan tip)</i>	Wash with warm, soapy water & sponge, pressure wash up to 1200 PSI <i>(with fan tip)</i>
Snow Removal	Only use a plastic edge shovel	Only use a plastic edge shovel
Ice Removal	Use snow/ice melt, DO NOT chip	Use snow/ice melt, DO NOT chip